

Operator manual –



English

A-2 / ENGLISH

TABLE OF CONTENTS Page Unpacking the MachineA-3 Cautions and WarningsA-4 Preparing the Machine for Use Installing the Brushes A-9 – A-10 Filling the Solution Tank......A-11 Squeegee InstallationA-11 Detergent (EcoFlex™) System.......A-12 – A-13 **Operating the Machine** Wet Scrubbing A-14 – A-15 Wet VacuumingA-15 After Using the MachineA-16 Servicing the Vacuum Motor......A-16 Lubricating the MachineA-16 Maintenance Charging the Batteries (Wet)......A-17 Charging the Batteries (Gel)......A-17 Servicing the SqueegeeA-18 Adjusting the SqueegeeA-18

Troubleshooting......A-19

INTRODUCTION

This manual will help you get the most from your **Nil** sk™ automatic scrubber/dryer. Read it thoroughly before operating the machine.

Note: Bold numbers in parentheses indicate an item illustrated on pages 5-8 unless otherwise noted.

This product is intended for commercial use only.

PARTS AND SERVICE

Repairs, when required, should be performed by your Authorized Nil sk Service Center, who employs factory trained service personnel, and maintains an inventory of Nil sk original replacement parts and accessories.

Call Nil sk for repair parts or service. Please specify the Model and Serial Number when discussing your machine.

MODIFICATIONS

Modi cations and additions to the cleaning machine which affect capacity and safe operation shall not be performed by the customer or user

without prior written approval from Nil sk A/S. Unapproved modi cations will void the machine warranty and make the customer liable for any resulting accidents.
NAMEPLATE
The Model and Serial Number of your machine are shown on the Nameplate in the battery compartment. This information is needed when ordering repair parts for the machine. Use the space below to note the Model and Serial Number of your machine for future reference.
Model
Serial Number
UNPACKING THE MACHINE
When the machine is delivered, carefully inspect the shipping packaging and the machine for damage. If damage is evident, save the shipping carton (if applicable) so that it can be inspected. Contact the Nil sk Customer Service Department immediately to le a freight damage claim. Refer to the unpacking instruction sheet included with the machine to remove the machine from the pallet.

CAUTIONS AND WARNINGS SYMBOLS

Nil sk uses the symbols below to signal potentially dangerous conditions. Read this information carefully and take the necessary steps to protect personnel and property.

⚠ DANGER!

Is used to warn of immediate hazards that will cause severe personal injury or death.

⚠ WARNING!

Is used to call attention to a situation that could cause severe personal injury.

Is used to call attention to a situation that could cause minor personal injury or damage to the machine or other property.



Read all instructions before using.

GENERAL SAFETY INSTRUCTIONS

Speci c Cautions and Warnings are included to warn you of potential danger of machine damage or bodily harm. This machine is for commercial use, for example in hotels, schools, hospitals, factories, shops and of ces other than normal residential housekeeping purposes.

↑ WARNING!

- * This machine should only be used by properly trained and authorized persons.
- * This machine is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge.
- * While on ramps or inclines, avoid sudden stops. Avoid abrupt sharp turns. Use low speed down ramps.
- * Observe the Gross Vehicle Weight, GVW, of the machine when loading, driving, lifting or supporting the machine.
- * Keep sparks, ame and smoking materials away from batteries. Explosive gases are vented during normal operation.
- * Charging the batteries produces highly explosive hydrogen gas. Charge batteries only in well-ventilated areas, away from open ame. Do not smoke while charging the batteries.
- * Remove all jewelry when working near electrical components.
- * Turn the key switch off (O) and disconnect the batteries before servicing electrical components.
- * Never work under a machine without safety blocks or stands to support the machine.
- * Do not dispense ammable cleaning agents, operate the machine on or near these agents, or operate in areas where ammable liquids exist.
- * Do not clean this machine with a pressure washer.
- * Do not operate this machine on ramps or inclines of more than a 2 percent gradient.
- * Only use the brushes provided with the appliance or those speci ed in the instruction manual. The use of other brushes may impair safety.
- Do not stare into laser. Class 1 Laser Product IEC 60825-1, 2007 AND 21CFR1040.10.

△ CAUTION!


- This machine is not approved for use on public paths or roads.
- This machine is not suitable for picking up hazardous dust.
- * Use care when using scari er discs and grinding stones. Nil sk will not be held responsible for any damage to oor surfaces caused by scari ers or grinding stones.
- * When operating this machine, ensure that third parties, particularly children, are not endangered.
- * Before performing any service function, carefully read all instructions pertaining to that function.
- * Do not leave the machine unattended without rst turning the key switch off (O), removing the key and securing the machine.
- * Turn the key switch off (O) and remove the key, before changing the brushes, and before opening any access panels.
- * Take precautions to prevent hair, jewelry, or loose clothing from becoming caught in moving parts.
- * Use caution when moving this machine in below freezing temperature conditions. Any water in the solution, recovery or detergent tanks or in the hose lines could freeze, causing damage to valves and tings. Flush with windshield washer uid.
- * The batteries must be removed from the machine before the machine is scrapped. The disposal of the batteries should be safely done in accordance with your local environmental regulations.
- * Do not use on surfaces having a gradient exceeding that marked on the machine.
- * All doors and covers are to be positioned as indicated in the instruction manual before using the machine.
- * Refer to the battery charger OEM product manual for additional speci c battery charger warnings.
- * Any use or adjustments of the Laser other than those specified herein may result in hazardous radiation exposure.

SAVE THESE INSTRUCTIONS

KNOW YOUR MACHINE

As you read this manual, you will occasionally run across a bold number or letter in parentheses - example: (2). These numbers refer to an item shown on these pages unless otherwise noted. Refer back to these pages whenever necessary to pinpoint the location of an item mentioned in the text. **NOTE:** Refer to the service manual for detailed explanations of each item illustrated on the next 4 pages.

- 1 Solution Tank Fill
- 2 Operator Control Handle
- 3 Bottle Holders
- 4 Recovery Tank Shutoff Float
- 5 Debris Tray
- 6 Recovery Tank Lid
- 7 Recovery Tank (Detergent Cartridge Access Cover)
- 7a Detergent Cartridge (EcoFlex models only)
- 8 Scrub Deck
- 9 Brush Housings (include Bristle Skirt)
- 10 Scrub Deck Bumper Wheel
- 11 Drive Wheel
- 12 Squeegee Assembly




A-6 / ENGLISH

KNOW YOUR MACHINE

- 13 Solution Drain Hose / Level Indicator
- 14 Squeegee Raise / Lower Lever
- 15 Battery Pack Connector
- 16 Recovery Hose
- 17 Wheel Drive Circuit Breaker (30 Amp)
- 18 Control Circuit Circuit Breaker (10 Amp)
- 19 Squeegee Blade Tension Strap
- 20 Squeegee Blade Latch
- 21 Squeegee Blade Alignment Pins
- 22 Squeegee Mount Thumb Nut
- 23 Squeegee Adjustment Knob
- 24 Recovery Tank Drain Hose

- 25 Debris Hopper (Cylindrical Models Only)
- 26 Idler Assembly (Cylindrical Models Only)
- 27 Solution Manifold (Cylindrical Models Only)
- 28 Control Panel (EcoFlex)
- 29 Drive Paddle
- 30 Speed Limit Control Knob
- 31 Onboard Battery Charger (Not found on all models)
- 32 Solution Filter
- 33 Solution Shut-Off Valve



CONTROL PANEL


- A Key Switch (Main Power)
- **B** Solution Increase Switch
- C Solution ON/OFF Switch
 - C1 Solution Flow Indicators (Normal, Heavy & Extreme)
- D Solution Decrease Switch
- E Detergent ON/OFF Switch
- F Display Panel
 - F1 Hour Meter
- F2 Solution Tank Level Indicator
- F3 Fault Codes
- F4 Detergent Indicator (if so equipped)
- F5 Detergent Ratio Indicator
- F6 Battery Indicator
- F7 Recovery Tank FULL Indicator
- F8 Battery Low Indicator

- **G** Scrub Pressure Increase Switch
- H Scrub ON/OFF Switch

(Disc System - Regular & Heavy)

(Cylindrical System - 1 Pressure Sensing)

- H1 Scrub Pressure Indicator
- I Scrub Pressure Decrease Switch
- J EcoFlex Switch
- K Brush Remove Switch (Disc Decks Only)
- L Vacuum/Wand Switch



BATTERIES

If your machine shipped with batteries installed do the following:

- Check that the batteries are connected to the machine (15).
- Turn ON the Key Switch (A) and check the Battery Indicator (F6 or E). If the gauge is completely lled or the green light is ON, the batteries are ready for use. If the gauge is less than full or the green light is OFF, the batteries should be charged before use. See the "Charging The Batteries" section.
- IMPORTANTI: IF YOUR MACHINE HAS AN ONBOARD BATTERY CHARGER REFER TO THE OEM PRODUCT MANUAL FOR INSTRUCTIONS REGARDING SETTING THE CHARGER FOR BATTERY TYPE.

If your machine shipped without batteries installed do the following:

- Consult your Authorized Nil sk dealer for recommended batteries.
- Install the batteries by following the instructions below.
- IMPORTANTI: IF YOUR MACHINE HAS AN ONBOARD BATTERY CHARGER REFER TO THE OEM PRODUCT MANUAL FOR INSTRUCTIONS REGARDING SETTING THE CHARGER FOR BATTERY TYPE.

⚠ WARNING!

Use extreme caution when working with batteries. Sulfuric acid in batteries can cause severe injury if allowed to contact the skin or eyes. Explosive hydrogen gas is vented from the batteries through openings in the battery caps. This gas can be ignited by any electrical arc, spark or ame. Do not install any lead-acid battery in a sealed container or enclosure. Hydrogen gas from overcharging must be allowed to escape.

When Servicing Batteries...


- Remove all jewelry
- * Do not smoke
- * Wear safety glasses, rubber gloves and a rubber apron
- * Work in a well-ventilated area
- * Do not allow tools to touch more than one battery terminal at a time
- * ALWAYS disconnect the negative (ground) cable rst when replacing batteries to prevent sparks.
- * ALWAYS connect the negative cable last when installing batteries.

△ CAUTION!

Electrical components in this machine can be severely damaged if the batteries are not installed and connected properly. Nil sk, a quali ed electrician, or the battery manufacturer should install batteries.

- 1 Remove the batteries from their shipping crate and carefully inspect them for cracks or other damage. If damage is evident, contact the carrier that delivered them or the battery manufacturer to le a damage claim.
- 2 Turn the Master Key Switch (A) OFF and remove the key.
- 3 Disconnect the Battery Pack Connector (15).
- 4 Tip the recovery tank to the side, locked position. Remove the battery cables from inside the battery compartment.
- Your machine comes from the factory with enough battery cables to install four 6 volt batteries. Carefully lift the batteries into the battery compartment and arrange them exactly as shown in FIGURE 1. Secure the batteries as close to the back of the machine as possible.
- 6 Install the battery cables as shown. Position the cables so the battery caps can be easily removed for battery service.
- 7 Carefully tighten the nut in each battery terminal until the terminal will not turn. Do not over-tighten the terminals, or they will be very dif cult to remove for future service.
- 8 Coat the terminals with spray-on battery terminal coating (available at most auto parts stores).
- 9 Put one of the black rubber boots over each of the terminals and connect the Battery Pack Connector (15).

When changing batteries or the charger, please contact your local authorized service center for correct battery, charger and machine settings to prevent battery damage.




INSTALLING THE BRUSHES (DISC SYSTEM)

△ CAUTION!

Turn the key switch off (O) and remove the key, before changing the brushes, and before opening any access panels.

- 1 Make sure the Brush Deck (8) is in the RAISED position. Make sure the Key Switch (A) is off (O).
- 2 If using pads, install the pads on the pad holders.
- 3 See Figure 2. To mount the Brushes (AA) (or pad holders) align the Lugs (BB) on the brush with the holes on the mounting plate and turn to lock in place (turn the outside edge of brush towards the rear of machine as shown (CC)).




A-10 / ENGLISH

INSTALL THE BRUSHES (CYLINDRICAL SYSTEM)

△ CAUTION!

Turn the key switch off (O) and remove the key, before changing the brushes, and before opening any access panels.

- 1 Make sure the Brush Deck is in the RAISED position. Make sure the Key Switch (A) is off (O).
- See Figure 3. To access the brushes loosen the black knobs (one on each side) on top of the idler assemblies (26) and remove the idler assemblies. Slide the brush into the housing, lift slightly, push and turn until it seats. Re-install the idler assemblies.



FILLING THE SOLUTION TANK


Fill the solution tank with a maximum of 94.6 Liters (25 gallons) of cleaning solution. Do not II the solution tank above 7.5 cm (3 inches) from the bottom of the Solution Fill (1). The solution should be a mixture of water and the proper cleaning chemical for the job. Always follow the dilution instructions on the chemical container label. **NOTE:** EcoFlex machines can either be used conventionally with detergent mixed in the tank or the EcoFlex detergent dispensing system can be used. When using the EcoFlex detergent dispensing do not mix detergent in the tank, plain water should be used.

△ CAUTION!

Use only low-foaming, non- ammable liquid detergents intended for machine application. Water temperature should not exceed 54.4 degrees celsius (130 degrees fahrenheit)

SQUEEGEE INSTALLATION

- 1 See Figure 4. Slide the Squeegee Assembly (12) onto the squeegee mount bracket and tighten the Squeegee Mount Thumb Nuts (22).
- 2 Connect the Recovery Hose (16) to the squeegee inlet.
- 3 Lower the squeegee, move the machine ahead slightly and adjust the squeegee tilt using the Squeegee Adjustment Knob (23) so that the rear squeegee blade touches the oor evenly across its entire width and is bent over slightly as shown.



DETERGENT SYSTEM PREPARATION AND USE (ECOFLEX MODELS ONLY)

COMMON INSTRUCTIONS:

Pressing and releasing the Detergent Switch **(E)** while the solution system is active will cause the detergent system to alternately turn on and off. The system should be purged of previous detergent when switching to a different detergent. **SERVICE NOTE:** Move machine over oor drain before purging because a small amount of detergent will be dispensed in the process.

To Purge When Changing Chemicals:

- 1 Disconnect and remove the detergent cartridge.
- Turn the Key Switch (A) ON. Press and hold the Solution Switch (C) and the Detergent Switch (E) down for 3 seconds. NOTE: Once activated the purge process takes 10 seconds. See illustration on next page for Detergent System indicators. Normally one purge cycle is adequate to purge the system.

To Purge Weekly:

- 1 Disconnect and remove the detergent cartridge. Install and connect a Cartridge lled with clean water
- 2 Turn the Key Switch (A) ON. Press and hold the Solution Switch (C) and the Detergent Switch (E) down for 3 seconds. NOTE: Once activated the purge process takes 10 seconds. See illustration on next page for Detergent System indicators. Normally one purge cycle is adequate to purge the system.

When the Detergent Cartridge is almost empty a Display Panel (F) indicator will come on. This "Low Detergent" indicator will remain on until you reset the system. Once this indicator comes on you should be able to simply pour an entire gallon bottle of detergent into the Cartridge to re II without worrying about measuring. NOTE: Only reset the system when the cartridge is full. When switching cartridges, the "Low Detergent" indicator is only accurate if the replacement cartridge is at the same level as the cartridge being replaced.

To Reset:

Turn the Key Switch (A) ON. Press and hold together the Solution Increase Switch (B) and the Solution Decrease Switch (D) down for 3 seconds. See illustration on next page for Detergent System indicators.


Detergent Percentage:


The detergent percentage default is 0.25%. To change the percentage, the detergent system must be OFF, then press and hold the Detergent ON/OFF Switch (E) for 2 seconds. The detergent indicator will ash and each press of the switch will cycle through the available percentages (3%, 2%, 1.5%, 1%, 0.8%, 0.66%, 0.5%, 0.4%, 0.3%., 0.25%). Once the desired percentage is displayed on the screen (F5), stop and it will lock in after 5 seconds.

CARTRIDGE SPECIFIC INSTRUCTIONS:

Fill the detergent cartridge with a maximum of 1.25 gallons (4.73 Liters) of detergent. **SERVICE NOTE:** Remove the detergent cartridge from the detergent box prior to lling to avoid spilling detergent on the machine.

It is recommended that a separate cartridge be used for each detergent you plan to use. The detergent cartridges have a white decal on them so you can write the detergent name on each cartridge to avoid mixing them up. When installing a new cartridge, remove the Cap (AA) and place the cartridge in the detergent box. Install the Dry Break Cap (BB) as shown.





WET SCRUBBING



Be sure you understand the operator controls and their functions. While on ramps or inclines, avoid sudden stops when loaded. Avoid abrupt sharp turns. Use low speed down hills. Clean only while ascending (driving up) the ramp.

To Scrub...

- 1 Follow the instructions in the Preparing The Machine For Use section of this manual.
- 2 Turn the Master Key Switch (A) ON (I). This will display the control panel indicator lights, reference the Battery Condition Indicator (F6) and Hour Meter (F1) before proceeding.
- To transport the machine to the work area, push the Drive Paddle (29) forward to go forward or pull the Drive Paddle (29) backward to move the machine in reverse. Vary the pressure on the Drive Paddle (29) to obtain the desired speed.
 - NOTE: Speed Control Knob (30) is used to control the maximum speed in either forward or reverse.
- 4 Press and hold the Solution Switch (C) for 5 seconds to pre-wet the oor. NOTE: This must be done prior to pressing the Scrub ON/OFF Switch (H).
- 5 Press the Scrub ON/OFF Switch (H), the scrub pressure will default to Normal (one scrub pressure indicator lit). Use the Scrub Pressure Increase Switch (G) and Scrub Pressure Decrease Switch (I) to change between Regular and Heavy Scrub modes. Only one pressure sensing is available for cylindrical machines. The solution ow rate will automatically adjust to coincide with the scrub pressure.
 - **NOTE:** The solution ow rate can be changed independently of the scrub pressure by pressing the Solution Increase Switch (B) or Solution Decrease Switch (D). Any subsequent scrub pressure adjustments will reset the solution ow rate to correspond with the scrub pressure.
 - **NOTE:** The scrub, solution, vacuum and detergent (EcoFlex models) systems are automatically enabled when the Scrub ON/OFF Switch (H) is pressed. Any individual system can be turned OFF or back ON by simply pressing its switch at any time during scrubbing. No further action is required other than lowering the squeegee (12).
- 6 Lower the squeegee with the Squeegee Raise / Lower Lever (14).
- When the Drive Paddle (29) is in the neutral position, the scrub, vacuum, solution and detergent (EcoFlex models) systems are activated but not running. Grip the Operator Control Handle (2) and push the Drive Paddle (29) forward to start the scrub, vacuum, solution and detergent (EcoFlex models), and to move the machine forward. For best results, move the machine at a slow walking speed. Press the Solution Switch (C) once to turn OFF while making sharp turns. Pull the Drive Paddle (29) backward to move the machine in reverse. The brushes will run while moving the machine in reverse, but solution and chemical will not be dispensed.



To avoid damaging the oor, keep the machine moving while the brushes are turning.

- When scrubbing, check behind the machine occasionally to see that all of the waste water is being picked up. If there is water trailing the machine, you may be dispensing too much solution, the recovery tank may be full, or the squeegee tool may require adjustment.
- The machine defaults to the EcoFlex cleaning mode (EcoFlex Switch Indicator is lit GREEN) conserving solution and detergent. Press the EcoFlex Switch (J) to override the EcoFlex cleaning mode and temporarily increase scrub pressure, solution ow and the detergent percentage. This will cause the indicator to ash (YELLOW) for one minute, solution ow rate will increase to the next level, scrub pressure will increase to the next level and the detergent percentage will increase to the next larger percentage.

 NOTE: Pressing and holding the EcoFlex Switch (J) for 2 seconds disables the EcoFlex system. The only way to re-enable is to push the EcoFlex Switch (J) again. Cycling the Key Switch (A) does not re-enable the system. The EcoFlex system will only function if the Scrub System (H) has been enabled.
- For extremely dirty oors, a one-pass scrubbing operation may not be satisfactory and a "double-scrub" operation may be required. This operation is the same as a one-pass scrubbing except on the rst pass the squeegee is in the up position. This allows the cleaning solution to remain on the oor to work longer. The nal pass is made over the same area, with the squeegee lowered to pick up the accumulated solution.
- The recovery tank has a shut-off oat (4) that causes ALL systems to turn OFF except the drive system when the recovery tank is full. When this oat is activated, the recovery tank must be emptied. The machine will not pick up water or scrub with the oat activated.
 - NOTE: All other indicators vanish and a "Recovery Tank FULL" Indicator (F7) turns on in the Display Panel when the switch is activated on "EcoFlex" models.
- When the operator wants to stop scrubbing or the recovery tank is full;
 - Press the Scrub ON/OFF Switch (H) once. This will automatically stop the scrub motors and the solution ow and the deck will raise to its upper limit. **NOTE**: The vacuum will stop after a 10 second delay. This is to allow any remaining water to be picked up without turning the vacuum back on.
- Raise the squeegee with the Squeegee Raise / Lower Lever (14). and drive the machine to a designated wastewater "DISPOSAL SITE" and empty the recovery tank. To empty, pull the Recovery Tank Drain Hose (24) from its hanger and open the cap (hold the end of the hose above the water level in the tank to avoid sudden, uncontrolled ow of waste water). The Recovery Tank Drain Hose (24) can be squeezed to regulate the ow. Re II the solution tank and continue scrubbing.

NOTE: Make sure the Recovery Tank Lid **(6)** and the Recovery Tank Drain Hose **(24)** cap are properly seated or the machine will not pick-up water correctly. When the batteries require recharging the Battery LOW Indicator **(F8)** will come on (EcoFlex models) and the vacuum motor will shut off after 30 seconds. Transport the machine to a service area and recharge the batteries according to the instructions in the Battery section of this manual.

WET VACUUMING


Fit the machine with optional attachments for wet vacuuming.

- 1 Disconnect the Recovery Hose (16) from the Squeegee (12).
- 2 Attach suitable wet pick-up tools to the hose (Available from Nil sk).
- 3 Turn the Master Key Switch (A) ON.
- 4 Press the Vacuum/Wand Switch (L) (EcoFlex models) once to turn ON the vacuum motor.

The vacuum motor will run continuously until the switch is pressed again to turn it OFF.

NOTE: The "Recovery Tank FULL" indicator is disabled when the wand mode is activated.

The oat will stop the ow into the recovery tank.



A-16 / ENGLISH

AFTER USE

- 1 Raise the brushes (or pads) and raise the squeegee. Move the machine to a service area.
- 2 Turn the Master Key Switch (A) OFF and remove the key.
- 3 To empty the solution tank, pull the Solution Drain Hose (13) off the upper connector. Direct the hose to a oor drain or bucket. Rinse the tank with clean water. Inspect the solution hoses; replace if kinked or damaged.
- To empty the recovery tank, remove the Recovery Tank Drain Hose (24) from its hanger and remove the cap (hold the end of the hose above the water level in the tank to avoid sudden, uncontrolled ow of waste water). The Recovery Tank Drain Hose (24) can be squeezed to regulate the ow. Rinse the recovery tank and shut-off oat (4) with clean water. Inspect the recovery and vacuum hoses; replace if kinked or damaged.
- Remove the brushes or pad holders. Rinse the brushes or pads with warm water and hang up to dry. Allow buf ng pads to dry completely before using again. **NOTE:** You can either remove the brushes manually or automatically by pressing the Brush Remove Switch (K) (EcoFlex disk models only).
- 6 Remove the squeegee, rinse it with warm water and hang it up to dry.
- 7 Check the maintenance schedule below and perform any required maintenance before storage.

MAINTENANCE SCHEDULE

MAINTENANCE ITEM	Daily	Weekly	Monthly	Yearly
Charge Batteries	X			
Check/Clean Tanks & Hoses	Χ			
Check/Clean/Rotate the Brushes/Pads	Χ			
Check/Clean the Squeegee	Χ			
Check/Clean Vacuum Shut-Off Float	Χ			
Empty/Clean Debris Tray In Recovery Tank	Χ			
Clean Hopper on Cylindrical System	Χ			
Check Each Battery Cell(s) Water Level (does not apply to gel cell batteries)		Χ		
Inspect Scrub Housing Skirts		Χ		
Inspect and clean Solution Filter		Χ		
Clean Solution Manifolds on Cylindrical System		Χ		
Purge Detergent System (EcoFlex only)		Χ		
Lubricate the Machine			Χ	
* Check Carbon Brushes				X

^{*} Have Nil sk check the vacuum motor carbon motor brushes once a year or after 300 operating hours. The brush and drive motor carbon brushes check every 500 hours or once a year.

NOTE: Refer to the Service Manual for more detail on maintenance and service repairs.

- 8 Store the machine in a clean, dry place.
- 9 Turn the Master Key Switch (A) OFF (O) and remove the key.


SERVICING THE VACUUM MOTOR

Have your Nil sk Dealer check the carbon motor brushes once a year or after 300 operating hours.

Δ

IMPORTANT!

Motor damage resulting from failure to service the carbon brushes is not covered under warranty. See the Limited Warranty Statement.



LUBRICATING THE MACHINE

Once a month, apply light machine oil to lubricate the:

- General Pivot Points For the Squeegee Linkage (A).
- Squeegee mount angle adjustment knob threads (B).
- Squeegee Tool end wheels (C).
- General Pivot Points For the Brush Linkage (D).
- Scrub deck bumper wheels.

Once per quarter, Grease the following

• Rear Caster Wheel Swivels (E).

CHARGING WET BATTERIES

EcoFlex - Charge the batteries each time the machine is used or when the Battery Indicator (F6) is reading less than full.



Do not II the batteries before charging.

Charge batteries in a well-ventilated area.

Do not smoke while servicing the batteries.

When Servicing Batteries...

- Remove all jewelry
- Do not smoke
- * Wear safety glasses, rubber gloves and a rubber apron
- * Work in a well-ventilated area
- * Do not allow tools to touch more than one battery terminal at a time
- * ALWAYS disconnect the negative (ground) cable rst when replacing batteries to prevent sparks.
- ALWAYS connect the negative cable last when installing batteries.

If your machine shipped with an onboard battery charger do the following:

Turn the Key Switch (A) OFF. Unwind the electrical cord from the side of the onboard charger and plug it into a properly grounded outlet. Refer to the OEM product manual for more detailed operating instructions.

If your machine shipped without an onboard battery charger do the following:

Disconnect the batteries from the machine and push the connector from the charger into the Battery Pack Connector (15). Follow the instructions on the battery charger. **SERVICE NOTE:** Make sure you plug the battery charger into the connector with the handle attached to it.



CAUTION!

To avoid damage to oor surfaces, wipe water and acid from the top of the batteries after charging.

CHECKING THE BATTERY WATER LEVEL

Check the water level of the batteries at least once a week.

After charging the batteries, remove the vent caps and check the water level in each battery cell. Use distilled or demineralized water in a battery lling dispenser (available at most auto parts stores) to II each cell to the level indicator (or to 10 mm over the top of the separators). DO NOT over- II the batteries!



CAUTION!

Acid can spill onto the oor if the batteries are over lled.

Tighten the vent caps. Wash the tops of the batteries with a solution of baking soda and water (2 tablespoons of baking soda to 1 liter of water).

CHARGING GEL (VRLA) BATTERIES

EcoFlex - Charge the batteries each time the machine is used or when the Battery Indicator (F6) is reading less than full.



WARNING!

Charge batteries in a well-ventilated area.

Do not smoke while servicing the batteries.

When Servicing Batteries...

- * Remove all jewelry
- Do not smoke
- Wear safety glasses, rubber gloves and a rubber apron
- * Work in a well-ventilated area
- * Do not allow tools to touch more than one battery terminal at a time
- * ALWAYS disconnect the negative (ground) cable rst when replacing batteries to prevent sparks.
- ALWAYS connect the negative cable last when installing batteries.



CAUTION!

Your voltage regulated lead acid (VRLA) battery will deliver superior performance and life ONLY IF IT RECHARGED PROPERLY! Under or overcharging will shorten battery life and limit performance. Be sure to FOLLOW PROPER CHARGING INSTRUCTIONS! DO NOT ATTEMPT TO OPEN THIS BATTERY! If a VRLA battery is opened, it loses its pressure and the plates become oxygen contaminated. THE WARRANTY WILL BE VOIDED IF THE BATTERY IS OPENED.

If your machine shipped $\underline{\text{with}}$ an onboard battery charger do the following:

Turn the Key Switch (A) OFF. Unwind the electrical cord from the side of the onboard charger and plug it into a properly grounded outlet. Refer to the OEM product manual for more detailed operating instructions.

If your machine shipped without an onboard battery charger do the following:

Disconnect the batteries from the machine and push the connector from the charger into the Battery Pack Connector (15). Follow the instructions on the battery charger. **SERVICE NOTE:** Make sure you plug the battery charger into the connector with the handle attached to it.

IMPORTANT: Make sure you have an appropriate charger for use on Gel cell batteries. Use only "voltage-regulated" or "voltage-limited" chargers. Standard constant current or taper current chargers MUST NOT be used. A temperature-sensing charger is recommended, as manual adjustments are never accurate and will damage any VRLA battery.

A-18 / ENGLISH

SERVICING THE SQUEEGEE

If the squeegee leaves narrow streaks or water, the blades may be dirty or damaged. Remove the squeegee, rinse it under warm water and inspect the blades. Reverse or replace the blades if they are cut, torn, wavy or worn.

To Reverse or Replace the Rear Squeegee Wiping Blade...

- 1 See Figure 5. Raise the squeegee tool off the oor, and then unsnap the Rear Squeegee Blade Removal Latch (20) on the squeegee tool.
- 2 Remove the Tension Strap (19).
- 3 Slip the rear blade off the Alignment Pins (21).
- The squeegee blade has 4 working edges. Turn the blade so a clean, undamaged edge points toward the front of the machine. Replace the blade if all 4 edges are nicked, torn or worn to a large radius.
- 5 Install the blade, following the steps in reverse order and adjust the squeegee tilt.

To Reverse or Replace the Front Squeegee Blade...


- 1 Raise the squeegee tool off the oor, then loosen the (2) Thumb Nuts (22) on top of the squeegee tool. Disconnect the Recovery Hose (16) and remove the squeegee tool (12) from the mount.
- 2 Loosen the Front Squeegee Blade Removal Knob (AA), then remove Tension Strap (AB) and blade...
- The squeegee blade has 4 working edges. Turn the blade so a clean, undamaged edge points toward the front of the machine. Replace the blade if all 4 edges are nicked, torn or worn to a large radius.
- 4 Install the blade, following the steps in reverse order and adjust the squeegee tilt.

ADJUSTING THE SQUEEGEE

Adjust the squeegee angle whenever a blade is reversed or replaced, or if the squeegee is not wiping the oor dry.

To Adjust the Squeegee Angle...

- 1 Park the machine on a at, even surface and lower the squeegee.
- While moving the machine forward slowly, turn the Squeegee Adjustment Knob (23) until the rear squeegee blade folds over evenly across the entire width of the squeegee as shown below.



GENERAL MACHINE TROUBLESHOOTING

Problem	Possible Cause	Remedy	
December 21 and a second	I Maria de la companya della companya de la company	B	
Poor water pick-up	Worn or torn squeegee blades	Reverse or replace	
	Squeegee out of adjustment	Adjust so blades touch oor evenly	
		across entire width	
	Recovery tank full	Empty recovery tank	
	Recovery tank drain hose leak	Secure drain hose cap or replace	
	Recovery tank cover gasket leak	Replace gasket / Seat cover properly	
	Debris caught in squeegee	Clean squeegee tool	
	Vacuum hose clogged	Remove debris	
	Using too much solution	Adjust solution ow at control panel	
	Foam Iter cover not seated	Seat cover properly	
Poor scrubbing performance	Worn brush or pad	Rotate or replace brushes	
	Wrong brush or pad type	Consult Nil sk	
	Wrong cleaning chemical	Consult Nil sk	
	Moving machine too fast	Slow down	
	Not using enough solution	Increase solution ow at control panel	
Inadequate solution ow	Solution tank empty	Fill solution tank	
	Solution tank empty Solution lines, valves, lter or trough	Flush lines, trough and clean solution lter	
or no solution	clogged	Flush lines, trough and clean solution liter	
	Solution shutoff valve closed	Open solution shutoff valve	
	Solution solenoid valve	Clean or replace valve	
	Colution Solenola Valve	Olean of replace valve	
Machine does not run	Battery connector disconnected	Reconnect battery connectors	
macrimic accomornan	Main system controller	Check error fault codes	
	Wall Gyotom controllor	(see service manual)	
	Tripped 10 Amp circuit breaker	Check for electrical short circuit & reset	
	The state of the s		
No FWD/REV wheel drive	Drive system speed controller	Check error fault codes	
		(see service manual)	
	Tripped 30 Amp circuit breaker	Check for drive motor overload	
	Emergency stop switch tripped	Reset the Emergency Stop Switch	
	Emergency step evitor anppod	record and Emorgoney stop switch	
Vacuum shuts off and display	Plugged squeegee hose	Clear debris	
shows	Vacuuming large amounts of water	Slow down or disable auto shut-off feature	
"Recovery Tank FULL indicator"	at a high travel speed	(see service manual)	
when recovery tank is not full			
Poor Sweeping Performance	Hopper Full	Empty and clean hopper	
(Cylindrical System)	Brushes worn	Replace brushes	
(Symianion System)	Bristles have taken a set	Rotate brushes	
No Detergent Flow (EcoFlex	Empty detergent cartridge	Fill detergent cartridge	
models only)	Plugged or kinked detergent ow line	Purge system, straighten lines to	
		remove any kinks	
	Dry seal cap on detergent cartridge not sealed	Reseat dry seal cap	
	Detergent pump wiring	Connect or reconnect wiring	
	disconnected or backwards		

A-20 / ENGLISH

TECHNICAL SPECIFICATIONS (as installed and tested on the unit)

Model		SC800-71	SC800-71C	SC800-86
Model No.		56112034	56112036	56112035
Voltage, Batteries	V	24V	24V	24V
Battery Capacity	Ah	312	312	312
Protection Grade		IPX4	IPX4	IPX4
Sound Pressure Level (IEC 60704-1)	dB(A)	61	61	61
Sound Pressure Level (IEC 60704-1) Uncertainty	dB(A)	3.0	3.0	3.0
Gross Weight	lbs / kg	1045 / 474.0	1065 / 483.1	1050 / 476.3
Transport Weight	lbs / kg	1035 / 469.5	1055 / 478.5	1040 / 471.7
Maximum Wheel Floor Loading (right front)	psi N/mm ²	73.5 / 0.507	75.3 / 0.519	74.0 / 0.510
Maximum Wheel Floor Loading (left front)	psi N/mm ²	68.0 / 0.469	69.9 / 0.482	68.6 / 0.473
Maximum Wheel Floor Loading (center rear)	psi N/mm²	287.6 / 1.983	287.6 / 1.983	287.6 / 1.983
Vibrations at the Hand Controls (ISO 5349-1)	m/s²	0.09	0.09	0.09
Vibrations at the Hand Controls (ISO 5349-1) Uncertainty	m/s²	0.02	0.02	0.02
Gradeability Transport		2% (1.15°)	2% (1.15°)	2% (1.15°)
Gradeability Cleaning		2% (1.15°)	2% (1.15°)	2% (1.15°)

MATERIAL COMPOSITION

	LBS	KG
Aluminum	13.58	6.16
Rubber	15.888	7.21
Plastic	23.037	10.45
Polyethylene	116.4	52.79
Ferrous Metal & Copper		
Transaxle	23	10.43
Brush Motor	17.25	7.82
Vac Motor	6	2.72
Other Electric	19.41	8.80



We supply a full range of cleaning equipment for rental or purchase.

For more information, or a cleaning solution to suit your business, please get in touch –

For a more comprehensive product range, please visit our website.



Address

Berrington House Berrington Road, Leamington Spa CV31 1NB

Contact

t: 0845 33 77 695 f: 0845 33 78 695 e: info@c-ind.co.uk